

Sombrilla Ombra. Ombra Folding parasol

Dirk Wynants



Uso y mantenimiento general. Care and general use

Para una óptima conservación de los muebles se recomienda limpiar periódicamente todos los elementos, como se indica en las instrucciones de limpieza, evitando así la acumulación de suciedad e impurezas.

En ambientes marinos o con elevada humedad (como SPA's, Beach Clubs,...) es recomendable extremar las precauciones de limpieza, especialmente en las colecciones con componentes de acero inoxidable.

Los muebles son resistentes a ralladuras e impactos bajo condiciones normales de uso. La exposición prolongada a temperaturas superiores a 60°C (140°F) puede causar daños en los materiales con los que están fabricados.

Con el fin de conservar el producto a lo largo del tiempo le recomendamos que:

- No usar limpiadoras de alta presión ni agua fuera del rango de 10-40 grados centígrados. En caso de utilizar cualquier otro producto o sistema de limpieza, el producto no quedará cubierto por la garantía.
- No arrastren el producto, al moverlo levántelo para no estropear las partes que apoyan en el suelo.
- Protejan el producto de los golpes y de contactos con objetos puntiagudos y cortantes, así como los líquidos o productos de limpieza que contengan agentes corrosivos.
- El producto es adecuado solo para viento ligero y/o lluvia ligera.
- Posicionar el producto en dirección de viento como se recomienda en el apartado de consejos sobre viento.
- No utilice el producto en condiciones climáticas adversas, como vientos fuertes, tormentas eléctricas, lluvias intensas o nieve. Asegúrese de cerrar y almacenar la sombrilla con anticipación.
- Cierre el producto y asegure la correa cuando no esté en uso.
- No utilice el producto sin su base o a menos que esté unido a la estructura del edificio, y mantenga el paraguas asegurado a la base del paraguas o al montaje en todo momento.
- No use productos sobre o cerca de productos químicos agresivos o llamas abiertas.
- Colocar el producto sobre superficie estable y nivelada.
- No permita que los niños ensamblen u operen el producto.
- Almacene el producto en interiores durante el invierno y las condiciones climáticas extremas.

- Al ajustar o ensamblar el paraguas o la base del paraguas, asegúrese de que los dedos de las manos, los pies o cualquier otra parte del cuerpo estén libres de partes móviles. No hacerlo puede resultar en lesiones graves.
- Utilizar únicamente piezas de repuesto Gandia Blasco.
- Cualquier modificación en el producto o el incumplimiento de los cuidados recomendados anulará la garantía.
- Los daños causados por el viento no están cubiertos por nuestra garantía limitada.
- Atégase a los consejos de mantenimiento que se dan en la correspondiente sección de la documentación adjunto al producto.

¡Advertencia!

En Gandia Blasco, nos esforzamos por ofrecer productos de alta calidad y durabilidad. Sin embargo, es crucial tener en cuenta que un uso descuidado o inapropiado de los tops de nuestras mesas puede ocasionar ralladuras o daños en los materiales, como aluminio lacado, aluminio anodizado, polietileno, madera, fenólico, porcelánico, mdi y mvi.

Para garantizar la óptima conservación de los tops de las mesas, recomendamos tratarlos con sumo cuidado y seguir estrictamente las instrucciones de mantenimiento proporcionadas. Es importante evitar el uso de objetos afilados, abrasivos o duros que puedan rayar la superficie. Asimismo, se debe evitar arrastrar objetos sobre el top de la mesa, ya que esto también puede causar daños.

Por favor, tenga en cuenta que nuestra garantía no cubre daños ocasionados por un uso inadecuado ni las ralladuras derivadas del desgaste cotidiano.

For an optimal conservation of the furniture, we recommend to clean all elements regularly, following the cleaning instructions, thus avoiding any accumulation of dirt and impurities on the furniture.

Nearby the sea or in atmospheres with a high humidity level (like SPAs, Beach Clubs, ...) we recommend to take additional cleaning precautions, specially in collections with stainless steel components.

The furniture is resistant to scratches and impacts under normal use conditions. Prolonged exposure to temperatures above 140°F (60°C) may harm the materials of which they are made.

In order to preserve the product over time we recommend:

- Do not use high-pressure cleaners or water outside the range of 10 to 40 degrees Celsius. If any other product or cleaning system is used, the product will no longer be covered by the warranty.
- Do not drag the product. When moving it, lift it so as not to scratch the parts that rest on the floor.
- Protect the product from bumps and from contact with pointy or sharp objects, as well as liquids or cleaning products with corrosive agents.
- Product is suitable for light wind and/or light rain only.
- Position the product in the direction of the wind as recommended in the wind tips section.
- Do not use product in inclement weather, such as strong wind, thunderstorms, heavy rain or snow, and make sure that the umbrella is closed and stored in advance.
- Close product and secure strap when not in use.
- Do not use product without its base or unless attached to building structure, and keep umbrella secured to umbrella base or mount at all times.
- Do not use product over or near harsh chemicals or open flames.
- Place product on stable and level surface.
- Do not allow children to assemble or operate product.
- Store product indoors during winter and extreme weather conditions.
- When adjusting or assembling the umbrella or umbrella base, make sure fingers, toes or any other parts of the body are clear from moving parts. Failing to do so may result in serious injury.
- Only use Gandia Blasco replacement parts.
- Any modifications to the product or failure to follow recommended care will void the warranty.
- Wind damage is not covered under our limited warranty.
- Follow the maintenance guidelines provided in the corresponding section of the document attached to the product.

Warning!

At Gandia Blasco, we strive to offer products of high quality and durability. However, it is crucial to take into account that careless or inappropriate use of our table tops can cause scratches or damage to the materials, such as lacquered aluminum, anodized aluminum, polyethylene, wood, phenolic, porcelain, MDI and MVI.

To ensure optimal preservation of the table tops, we recommend treating them with the utmost care and strictly following the maintenance instructions provided. It is important to avoid using sharp, abrasive or hard objects that could scratch the surface. Also, avoid dragging objects across the top of the table, as this can also cause damage.

Please note that our warranty does not cover damage caused by improper use or scratches from everyday wear and tear.

Limpieza. Cleaning

Aluminio termolacado. Powder-coated aluminium

Limpiar con agua y jabón neutro con un trapo suave. No utilizar productos de limpieza que contengan disolventes ni blanqueantes (lejía). No utilizar estropajos ni cepillos de metal.

Clean with water and neutral soap with a soft cloth. Do not use products containing solvents or bleaching agents. Do not use scourers or metal brushes.

Tejido Solidum. Solidum Fabric

La tela Skycover es una tela de exterior altamente resistente a la radiación UV y a los agentes atmosféricos, con una buena estabilidad dimensional y un fácil mantenimiento, concebida para durar mucho tiempo. Está especialmente diseñada para velas de sombrillas.

Las manchas son con frecuencia el resultado de una acumulación progresiva de pequeñas cantidades de partículas transportadas por el aire o la lluvia. Otras suciedades están directamente asociadas al uso doméstico del tejido (alimentos, bebidas...).

Se recomienda:

- Quitar el polvo al tejido con un aspirador o un cepillo suave no metálico.
- Lavar con un paño suave o una esponja utilizando agua y jabón neutro.
- Para manchas difíciles utilizar un desengrasante común o una disolución de amoníaco rebajado con agua:
 - Pulverizar directamente sobre la superficie a limpiar.
 - Dejar actuar durante 30-45 segundos.
 - Frotar con un salvauñas o paño.
 - Aclarar con agua o una esponja húmeda.
 - En caso de persistir la suciedad, repetir la operación.

Skycover fabric is a high-performance outdoor fabric with excellent UV resistance and weatherability, good dimensional stability, and easy maintenance, designed for long-lasting use. It is specifically designed for shade sail applications.

Some stains appear as a result of the progressive build-up of small particles transported by air or rain. Other stains are directly linked to the domestic use of the fabric (food, beverages...).

The following washing procedure is recommended:

- Remove dust from the fabric using a vacuum cleaner or a soft non-metal brush.
- Wash with a soft cloth or sponge using water and mild soap.
- For difficult stains use a spray common degreasing agent or a solution of ammonia diluted in water:
 - Spray directly on the required surface.
 - Leave for between 30-45 seconds.
 - Rub with a sponge or cloth.
 - Rinse with water or a damp sponge.
 - Repeat if the stain remains.

Símbolos. Symbols

